
3-5. Other interior features Sun visors



- 1 Forward position: Flip down
- 2 Side position: Flip down, unhook, and swing to the side

Vanity mirror and light



1 The vanity light turns on.



■ To prevent battery from being discharged

Do not leave the vanity light on for extended periods while the engine is stopped.

3-5. Other interior features Clock



H button : Adjusts the hour.

: Adjusts the 2 M button

minutes.

3 :00 button : Resets the

minutes to zero.*

* For example: 9:30 to 9:59 displayed \rightarrow 10:00 10:01 to 10:29 displayed \rightarrow 10:00

3-5. Other interior features **Ashtray**



Press the lid to open.

■ Removing the ashtray

Pull the ashtray up to remove it.

A CAUTION

■ After use

Keep the ashtray closed.


Injuries may result in the event of sudden braking, sudden swerving or an accident.

■ To prevent causing a fire

- Fully extinguish matches and cigarettes before putting them in the ashtray, then make sure it is fully closed.
- Do not place paper or any other type of flammable object in the ashtray.

3-5. Other interior features Cigarette lighter

Open the ashtray lid and push the cigarette lighter down.



The cigarette lighter will pop up when it is ready for use.

■ Cigarette lighter operating conditions

The engine switch must be turned to "ACC" or "ON" position for the cigarette lighter to operate.



A CAUTION

■ To avoid burns and fires

- Do not touch the metal portions of the cigarette lighter.
- Do not hold the cigarette lighter down. It could overheat and cause a fire.
- Do not insert anything other than the cigarette lighter provided into the outlet.

3-5. Other interior features Power outlet

The power outlet can be used for 12 V accessories that run on less than 10 A.



1 Open

■ Power outlet operating conditions

The engine switch must be turned to ACC or ON.



■ To avoid damaging the power outlet

Close the power outlet lid when the power outlet is not in use.

Foreign objects or liquids that enter the power outlet may case a short circuit.

■ To prevent the fuse from being blown

Do not use the an accessory that uses more than 12 V 10 A.

■ To prevent the battery from being discharged

Do not use the power outlet longer than necessary when the engine is not running.

3

Interior features

3-5. Other interior features **Seat heaters**



- 1 Turn the dials to the left to turn the respective seat heaters on.
- 2 To turn off, turn the dials to the right until they stop.

■ Operating conditions

The engine switch must be in the ON position.

A CAUTION

■Burns

- Use caution when seating the following persons in a heated seat to avoid the possibility of burns:
 - Babies, small children, elderly persons, sick persons or handicapped persons
 - Persons who have delicate skin
 - · Persons who are exhausted
 - · Persons who have taken alcohol or drugs that induce sleep (sleeping drug, cold remedy, etc.)
- Do not cover the seat with anything when using the seat heater. The seat heaters may overheat if the seat is covered.

3-5. Other interior features

↑ NOTICE

■ To prevent seat heater damage


Do not put unevenly weighted objects on the seat and do not stick sharp objects (needles, nails, etc.) into the seat.

■ To prevent battery discharged

Turn the switches off when the engine is not running.

3-5. Other interior features Floor mats

Use only genuine Lexus floor mats properly secured to the vehicle carpet.



Secure the mat with the lock clips.

A CAUTION

■ When inserting the floor mat

Observe the following precautions. Failure to do so may result in the floor mat slipping and interfering with the movement of the pedals during driving, resulting in an accident.

- Make sure the floor mat is properly placed on the vehicle carpet and the correct side faces upward.
- Do not place floor mats on top of existing mats.

3-5. Other interior features Trunk features

■ Cargo hooks




Cargo hooks are provided for securing loose items.

■ First-aid kit space



This space is provided to accommodate the first-aid kit.



1 Pull it out

- 11 Hook it on the anchors
- 2 Secure the strap on the tire or luggage cover

A CAUTION

■ Luggage cover

STEP 1

■ When not in use

To avoid injury, always return the cargo hooks to their positions under the carpet when they are not being used.

3-5. Other interior features Garage door opener

The garage door opener can be programmed to operate garage doors, gates, entry doors, door locks, home lighting systems, and security systems, and other devices.

The garage door opener (HomeLink $^{\circledR}$ Universal Transceiver) is manufactured under license from HomeLink $^{\circledR}$.

Programming the HomeLink® (for U.S.A. owners)

The HomeLink® compatible transceiver in your vehicle has 3 buttons which can be programmed to operate 3 different devices. Refer to the programming method below appropriate for the device.



- Indicator light
- 2 Buttons

 \blacksquare Programming the HomeLink $^{\circledR}$

Point the remote control for the device 1 to 3 in. (25 to 75 mm) from the HomeLink $^{\otimes}$ control buttons.

Keep the indicator light on the HomeLink® in view while programming.



Simultaneously press and hold the transmitter button along with one of the HomeLink[®] buttons.



When the indicator light on the HomeLink® changes from a slow to a rapid flash after 20 seconds, you can release both buttons.

Test the operation of the HomeLink® by pressing the newly programmed button.

If programming a garage door opener, check to see if the garage door opens and closes. If the garage door does not operate, see if your garage transmitter is of the "Rolling Code" type. Press and hold the programmed HomeLink button. The garage door has the rolling code feature if the indicator light (on the HomeLink has rapidly and then remains lit after 2 seconds. If your transmitter is the "Rolling Code" type, proceed to the heading "Programming a rolling code system".

STEP 5 Repeat the steps for each remaining HomeLink® button to program another device.

■ Programming a Rolling Code system (for U.S.A. owners)

If your device is "Rolling Code" equipped, follow the steps under the heading "Programming the HomeLink®" before proceeding with the steps listed below.

Description of the learn button on the ceiling mounted garage door opener motor. The exact location and color of the button may vary by brand of garage door opener.

Refer to the owner's guide supplied by the garage door opener manufacturer for the location of this learn button.

Press the learn button on the ceiling mounted garage door opener motor.

Press and hold the vehicle's programmed HomeLink® button for 2 seconds and release it. Repeat this step once again. The garage door may open.

If the garage door does open, the programming process is complete. If the door does not open, press and release the button a third time. This third press and release will complete the programming process by opening the garage door.

The ceiling mounted garage door opener motor should now recognize the HomeLink $^{\!@}$ transceiver and operate the garage door.

Repeat the steps for each remaining HomeLink® button to program another rolling code system.

■ Programming an entrance gate (for U.S.A. owners)/Programming all devices in the Canadian market

- Place the remote control for the device 1 to 3 in. (25 to 75 mm) away from the HomeLink® control buttons.
 - Keep the indicator light on the HomeLink® in view while programming.
- STEP 2 Press and hold the selected HomeLink® button.
- Repeatedly press and release (cycle) the device remote control button every two seconds until step 4 is completed.
- When the indicator light on the HomeLink® compatible transceiver start to flash rapidly, release the buttons.
- STEP 5 Press the newly programmed HomeLink® button to see if it operates the device.
- Repeat the steps for each remaining HomeLink® button to program another device.

■ Programming other devices

To program other devices such as home security systems, home door locks or lighting, contact your authorized Lexus dealer for assistance.

■ Reprogramming a button

The individual HomeLink® buttons cannot be erased but can be reprogrammed. To reprogram a button, follow the "Basic programming" instructions.

Operating the HomeLink®

Press the appropriate HomeLink® button. The HomeLink® indicator light on the HomeLink® transceiver should turn on.

The HomeLink $^{\otimes}$ continues to send the signal for up to 20 seconds as long as the button is pressed.

Erasing the entire HomeLink® memory (all three programs)

Press and hold down the 2 outside buttons for 20 seconds until the indicator light flashes.

If you sell your vehicle, be sure to erase the programs stored in the $\mathsf{HomeLink}^{\circledR}$ memory.

■ Before programming

- Install a new battery in the transmitter.
- The battery side of the transmitter must be pointed away from the HomeLink®.

■ Certification for the garage door opener

This device complies with Part 15 of FCC Rules and with RSS-210 of the IC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: This transmitter has been tested and complies with FCC and IC rules. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

A CAUTION

■ When programming a garage door or other remote control device

The garage door may operate, so ensure people and objects are out of danger to prevent potential harm.

■ Conforming to federal safety standards

Do not use the HomeLink $^{\circledR}$ compatible transceiver with any garage door opener or device that lacks the safety stop and reverse features as required by federal safety standards.

This includes any garage door that cannot detect an obstructing object. A door or device without these features increases the risk of injury or death.

3-5. Other interior features

206